



PART NO.

QUANTITY

DESCRIPTION

D1258R-12 D1258R-24

PART NO.	QUANTITY	QUANTITY	DESCRIPTION
	D1258R-12	D1258R-24	
211	2	2	Front Body Extrusion/Rear Body Extrusion
231	1	1	R.H. End Housing
241	1	1	L.H. End Housing
251	1	1	Body Cover
260	8	8	End Housing Screws
270	6	6	Clamp Bar T Bolts/Jig Hold Down T Bolts
281	4	4	Fixed Side Stops
282	4	4	Angle Side Stops
283	10	10	Side Stop, Angle Side Stop and Jig Hold Down Flat Washers
284	4	4	Angle Side Stop Square Nuts (1/4 x 20)
285	4	4	Angle Side Stop Bolts (1/4 x 20)
290	6	6	Clamp Bar Bolt Loc Washers
300	6	6	Clamp Bar Bolt Nuts/Hold Down Bolt Nuts (5/16 x 18)
310	4	4	Clamp Bar Springs
320	4	4	Clamp Bar Knobs
330	2	2	Clamp Bars (c/w End Plugs)

PART NO.

QUANTITY

DESCRIPTION

D1258R-12 D1258R-24

PART NO.	QUANTITY	QUANTITY	DESCRIPTION
	D1258R-12	D1258R-24	
340	4	4	Clamp Bar End Plugs
351	1	1	R.H. Support Bracket
361	1	1	L.H. Support Bracket
370	2	2	Support Bracket Knobs
371	2	2	Support Bracket Knob Washers, Nylon
391	1	1	R.H. Scale Assembly, Complete (R.H. in "HB" Tail Mode)
393	1	1	L.H. Scale Assembly, Complete (L.H. in "HB" Tail Mode)
400	2	2	Scale Screws (8-32)
422	2	2	Cross Cut Bar Cap
431	1	1	Cross Cut Bar (1/4 x 1/4 CRS)
441	1	1	HB Pin Guide Rail (1/4 x 1/4 CRS)
451	1	1	Finger Guide Rail (1/4 x 3/4 CRS)
460	10	13	R.H. Finger c/w Bevel Nut and Screw
470	10	13	L.H. Finger c/w Bevel Nut and Screw
480	10	13	R.H. Finger Bevel Nut
490	10	13	L.H. Finger Bevel Nut

PART NO.**QUANTITY****DESCRIPTION**

D1258R-12 D1258R-24

500	20	26	Finger Lock Screws (8-32 x 310" P.H.)
540	1	1	Leigh Assembly Wrench/Gauge
550	1	1	Finger Adjusting Screwdriver (#2 Robertson)
#80	1	1	1/2" x 8° x 13/16 Deep Dovetail Cutter (Not Illus.)
#140	1	1	5/16" Straight Cutter (Not Illus.)
Note			Cutters Often Shipped Separately by Supplier.
	1	1	Instruction Manual
	1	1	Assembly Instructions
