

Optional router bits for variably spaced through and half-blind dovetails.





# Through Dovetail Bit Selection

### 8° Dovetail Bit for Tails

**The pins** ① must fit into the pin sockets ②. Therefore the dovetail bit's depth of cut <sup>®</sup> must be equal to or a little greater than the pin board thickness ③.

Measure the pin board thickness (3)

**Select** the dovetail bit with the correct depth of cut <sup>®</sup> from the following pages (bits must be 8° for through dovetails).

### **Straight Bit for Pins**

The matching straight bit is listed on the charts with the dovetail bit.

### **Dovetail Bit Angle**

All through dovetail bits must be 8°. This angle matches the D4R Pro guide finger pin angle. If you try to use a different angle of dovetail bit, there will be a mismatch between the pins routed at 8°.


## Guidebush

All 8mm shank through dovetail bits listed in this appendix work with the e7-Bush ( $7_{16}$ " OD [11,1mm]) supplied with your Leigh jig, or any  $7_{16}$ " OD [11,1mm] guidebush. The optional Leigh 716C guidebush or standard 5/8" OD [15,9mm] guidebush is used with  $\frac{1}{2}$ " [12,7mm] shank bits. No other guidebush sizes can be used for through dovetails. *See page 70.* 

## **Shank Selection**

The Leigh D4R Pro comes with one through dovetail bit and one straight bit, with 8mm shanks, plus a  $\frac{1}{2}$ "[12,7mm] to 8mm collet reducer. The reducer ④ simply slides into the  $\frac{1}{2}$ "[12,7mm] collet ⑤ of your router and the 8mm shank bit is inserted into the collet reducer. The collet is tightened as normal. The collet reducer is not required with  $\frac{1}{2}$ "[12,7mm] shank bits.

Note: ④ is a collet reducer, not a collet ⑤. The reducer does not replace the collet, it slides directly into your collet.



Note that some of the dovetail bits' depths of cut overlap. For example: No.70-8 bit (B) :  $\frac{1}{4}$ " -  $\frac{1}{2}$ " [6 - 13mm] No.75-8 bit (B) :  $\frac{3}{8}$ " -  $\frac{5}{8}$ " [9,5 - 16mm] No.80-8 bit (B) :  $\frac{1}{2}$ " -  $\frac{13}{16}$ " [12 - 20mm]

This means all three bits are capable of routing boards ½" [12,7mm] thick using one of the following combinations: No.80-8 and 140-8, No.75-8 and 140-8, or No.70-8 and 140-8.


The three bit combinations will produce slightly different-looking joints because each dovetail bit produces a different size diameter of pin: No.70-8 (1) :  $\frac{3}{8}$ " No.75-8 (2) :  $\frac{7}{16}$ "

No. 80-8  $3:\frac{1}{2}$ 

Do not attempt to rout dovetails at less than the minimum depth


of cut specified, as the bit can hit the guide fingers or guide bushing.


### Leigh Through Dovetail Bits Note: Bit and joint drawings are about actual size.




Numbers in brackets are millimeters \*An extra step is required to rout joints with a cutting depth greater than 1"[26,0]


#### Note: Bit and joint drawings are about actual size.








\* Bits 80-8, 120-8, and 140-8 come standard with the Leigh D4R Pro





Bits	A Overall Diameter	B / G Cutting Depth Range	C Shank Diameters	D Shank Length	E Overall Length	F Angle	Guidebush Diameter
No. 50-8	1/4" [6,35]	<b>B</b> 1/8" to 1/4" [3,0-7,0]	8mm	1-3/4" [45,0]	2" [50,0]	8°	e7 or 7/16"[11,1]
No. 140-8*	5/16" [7,9]	<b>G</b> 1/8" to 1" [3,0-26,0]	8mm	1-3/4" [45,0]	2-3/4" [70,0]	-	e7 or 7/16"[11,1]

## Half-Blind Dovetail Bit Selection

#### **Bits:**

The same dovetail bit routs both parts of a half-blind dovetail.

#### **Flush Drawers:**

The dovetail bit's working depth of cut (B) must be less than the pin board thickness (1) for flush drawers by at least  $\frac{1}{8}$ "[2mm].

#### **Rabbeted Drawers:**

The dovetail bit's working depth of cut (B) must be about  $\frac{1}{16}$ "[1mm] less than the rabbet depth (2) for rabbeted drawer fronts.

#### Drawer Sides (Tail Board):

Minimum thickness is  $\frac{1}{4}$ "[6mm]. Drawer side thickness (3) does not affect bit selection.

Note: <sup>(B)</sup> is the nominal working depth for half-blind dovetails, not the maximum depth. <sup>(B)</sup> must not be varied, except for minor adjustments for joint fit. *See page 37.* 

### Selecting the Bit

**Measure** the drawer front thickness (minimum  $\frac{1}{2}$ "[12mm]) ① or rabbet depth (minimum  $-\frac{7}{16}$ "[11mm]) ②.

**Select** a bit with the appropriate depth of cut (B) from the following pages. *Can I use any dovetail bit?* No, all half-blind bits must be <sup>1</sup>/<sub>2</sub>" [12,7mm] diameter. As the angle changes, so does the depth of cut. Using bits that are a different angle and diameter will result in joints that don't fit, and could damage the jig.


#### Guidebush


All 8mm shank half-blind dovetail bits listed in this appendix work with the e7-Bush (7/16" OD [11,1mm]) supplied with your Leigh jig, or any 7/16" OD [11,1mm] guidebush. No other guidebush sizes can be used for half-blind dovetails. *See page 70.* 




The Leigh D4R Pro comes with two half-blind bits with 8mm shanks, plus a  $\frac{1}{2}$ "[12,7mm] to 8mm collet reducer. The reducer ④ simply slides into the  $\frac{1}{2}$ "[12,7mm] collet ⑤ of your router, and the 8mm shank bit is inserted into the collet reducer. The collet is tightened as normal. The collet reducer is not required with  $\frac{1}{2}$ "[12,7mm] shank bits. For a  $\frac{1}{2}$ "[12,7mm] collet you will require the included  $\frac{1}{2}$ "[12,7mm] to 8mm collet reducer, No. 172-8.


Note: ④ is a collet reducer, not a collet ⑤. The reducer does not replace the collet, it slides directly into your collet.







## Leigh Half-Blind Dovetail Bits








#### Note: Bit and joint drawings are about actual size.





This page is left blank intentionally.